

AMAZON FIRE TV STICK

Remote Guide

VOICE COMMAND

Activates voice search

BACK

Tap: Takes you to Main Menu inside PulseTV
Hold: Takes you to device Main Menu outside PulseTV

REWIND

VOLUME (+/-)
Controls volume if device is paired with TV

NAVIGATION

SELECT

HOME

Takes you outside of the PulseTV app

MENU

Various functions depending on screen

FAST FORWARD

PLAY/PAUSE

MUTE

Mutes volume if device is paired with TV



VOICE COMMAND NOTE:

To search within PulseTV's App:

Navigate to the search icon in the main menu, then select the microphone icon on your remote to activate voice control..