

SET-TOP BOX

Remote Guide

INFO

Inside App:
Displays info
about what
you're watching



POWER

TV APP

TV APP

Launches PulseTV
App from device
main menu

GUIDE

Inside App:
Takes you to the
traditional-style
PulseTV guide



VOD

Inside App:
Takes you to the
selection menu for
movies

HOME

Takes you to
the home of
the set-top box
(outside PulseTV)



PAGE (up/down)

Inside App:
Page (up) and
page (down)
within the guides

VOLUME (+/-)

Controls volume
if device is
paired with TV



GOOGLE ASSISTANT

Searches for your
voice command
request outside
of PulseTV App

MENU

Inside App: Takes
you to main menu



VOICE COMMAND NOTE:

To search within PulseTV's App:
Navigate to the search icon in
the main menu, then select the
microphone icon on the screen to
activate voice control. Using the
Google Assistant button on the
remote will exit the PulseTV app.

ARRIS